


euø style

Assembly Instructions

HANH Activity Table


PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, call Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com



A (1 pc)



B (4 pcs)



C (24 pcs)
M.25 x 20mm



D (24 pcs)



E (24 pcs)



F (1 pc)
4mm

