
## eurøstyle

Assembly Instructions TENDY Pro Side Chair STEP 1: Move the bumper to bumper stop point (against it, not over it)

STEP 2: Attach the base to the seat plate by firstly afixing, by hand, all bolts (part C) together with the lock washers (part D) and large washers (part E) to the seat plate, then tightening them up with the allen wrench (part F)



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com

ATTENTION: WHEN ATTACHING THE BASE TO THE SEAT SHELL, PLEASE MAKE SURE THAT THE DIRECTION ARROW ON THE BASE PLATE IS POINTING TO THE FRONT OF THE CHAIR.