

# euro style™


## Assembly Instructions

### BETH Dining Table



PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.

A (1 PC) B (4 PCS) C (4 PCS) D (4 PCS) E (4 PCS) F (4 PCS) G (4 PCS) H (1 PC)



During assembly, hand tighten screws only. When all screws are in place, then tighten completely.