


# eurowstyle™


## Assembly Instructions

### AXEL Low Back w/o Armrests


PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: [claims@gotoeurostyle.com](mailto:claims@gotoeurostyle.com)




2



3



4



A (1 pc)



F (5 pcs)



B (1 pc)



G (2 pcs)



C (1 pc)



H (12 pcs)



D (1 pc)



I (12 pcs)



E (1 pc)



J (1 pc)



K (1 pc)

