eurøstyle.

Assembly Instructions BISTRO Table





A (1 pcs)





D (1 pc)





E (8 pcs)

Ø1/4" X 1"

1100000000


 \square

F (8 pcs)

Ø1/4" X 5/8"

C (4 pcs)

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com



During assembly, hand tighten screws only. When all screws are in place, then tighten completely.