
## eurøstyle.

Assembly Instructions CROSBY High Back Office Chair







PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com

2


Κ





6mm

8mm



Ó



During assembly, hand tighten screws only. When the screws are in place, tighten completely.

Revised 04.20.15 cy