


Assembly Instructions HANH Left Desk




PLEASE NOTE: Check that you have received all components and hardware before assembling.
If you are missing any parts, contact your retailer,
or fax Euro Style at 415.455.8033.


1



2



3



A (1 pc)



B (1 pc)



C (4 pcs)



D (3 pcs)



E (24 pc)

M.25 x 20mm



F (3 pc)

M.25 x 45mm



G (27 pcs)



H (27 pcs)



I (1 pc)
4mm