

Assembly Instructions RADINKA Side Table

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com



A (1 pc)




B (1 pc)
M8 x 35mm



C (1 pc)



D (5 pcs)



E (1 pc)



F (1 pc)



G (1 pc)




H (1 pc)




I (1 pc)
5mm


1




2



3



4



DESCENT CONTROL SCREW
Tighten the pre-installed screw located on bottom of Part G to expand rubber washer and slow rate of descent. Loosen screw to decrease resistance and allow for less restricted movement.

QUICK-RELEASE ADJUSTABLE LEVER

Hold table top securely while adjusting table height. Lock lever in place once desired height is reached.

During assembly, hand tighten screws only. When all screws are in place, then tighten completely.