

euø style™

Assembly Instructions RAYDEN Dining Table

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033 or email: claims@gotoeurostyle.com.

