eurøstyle.

Assembly Instructions

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.

Daniel Coffee C (1 pc) D (2 pcs) А (1 pc) B (2 pčs) Ø E (2 pcs) H (8 pcs) F (1 pc) G (2 pcs) 0) \bigcirc I (4 pcs) J (4 pcs) K (4 pcs) L (1 pc) 1. 2. F В В В 3. Α

During assembly, hand tighten screws only. When all screws are in place, then tighten completely.