









# eurow style™

## Assembly Instructions

Sam



-  **B** x2PC
-  **C** x2PCS
-  **D** x1PC
-  **E** x1PC
-  **G** x4PCS
-  Tool

**PLEASE NOTE:** Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.